

### 6.3.4 Summary to: 6.3 Chemical Vapor Deposition

- Chemical Vapor Deposition (CVD) is simple in principle
  - Find to gases that react of the desired material at elevated temperatures
  - Put your wafer(s) into some machine, evacuate, heat to the desired temperature (preferably only the wafers) and admit the gases (and remove undesired reaction products).
  - There are many quite different technical ways (all of them expensive) to realize a **CVD** apparatus

Major **CVD** process are

Deposition of epitaxial **Si** layers - obviously always on (atomically clean) **Si** substrates. By admitting some gases carrying doping atoms (e.g. **AsH<sub>3</sub>**, **AsH<sub>3</sub>**) the layer can be doped in-situ.

Deposition of poly crystalline **Si** layers.

- Chemically similar to epitaxial layers, in reality quite different because the CVD reactos can be simpler.
- Poly-**Si** is needed for many uses: Gate electrode, interconnect, filling of holes, sacrificial layer.
- Its great advantage is its ull compatibility with **Si** and **SiO<sub>2</sub>**; its great disadvantage is its mediocre conductivity (for heavy doping).


Deposition of **Si<sub>3</sub>N<sub>4</sub>**

- Very important. Always prone to produce mechanical stress (**Si<sub>3</sub>N<sub>4</sub>** is an unyielding ceramic!).


**W** (and Silicides, and ...)

- Not "good" processes, but sometimes unavoidable!


**Epitaxial Si layer**




**Polycrystalline Si layer**




**SiO<sub>2</sub> layer** ("TEOS process)



**Si<sub>3</sub>N<sub>4</sub> layer**



**W layer**



## Questionnaire

Multiple Choice questions to all of 6.3