

Depletion

This is the case where an electrical field of arbitrary origin repulses the majority carriers and a space charge region develops.

Starting with the [Poisson equation for doped semiconductors and all dopants ionized](#), we have

$$\frac{d^2(\Delta E_C)}{dx^2} = - \frac{e^2 \cdot N}{\epsilon \epsilon_0} \left(1 - \exp - \frac{\Delta E_C}{kT} \right)$$

In contrast to the case of [quasi-neutrality](#), we now have $+\Delta E_C \gg kT$ and *the sign is important!*

This leads to a simple approximation:

$$\exp - \frac{\Delta E_C}{kT} \approx 0$$

The Poisson equation for the part of the semiconductor that contains this carrier density reduces to

$$\frac{d^2(\Delta E_C)}{dx^2} = - \frac{e^2 \cdot N_D}{\epsilon \epsilon_0}$$

We have [treated this case already](#) in the more basic considerations. The result was

$$U(x) = \frac{e \cdot N_D}{2\epsilon \epsilon_0} \cdot x^2 - 2d_{SCR} \cdot x + d_{SCR}^2$$

$$d_{SCR} = \frac{1}{e} \cdot \left(\frac{2\Delta E_C(x=0) \cdot \epsilon \epsilon_0}{N_D} \right)^{1/2}$$

With $\Delta E_C(x=0) = \Delta E$ for brevity, we can rewrite the expression for the width of the space charge layer in terms of the [Debye length \$L_{Db}\$](#)

$$L_{Db} = \left(\frac{\epsilon \epsilon_0 \cdot kT}{e^2 \cdot N_D} \right)^{1/2}$$

and obtain

$$d_{SCR} = L_{Db} \cdot \left(\frac{2\Delta E}{kT} \right)^{1/2}$$

If we express ΔE in terms of the the voltage U between the ends of the sample by $e \cdot U = \Delta E$, we have the final result

$$d_{SCR} = L_{Db} \cdot \left(\frac{2 \cdot e \cdot U}{kT} \right)^{1/2}$$

- Remember that L_{Db} is a purely material related quality and thus a *constant* for a given semiconductor. The width of the space charge region can be expressed very simply in terms of L_{Db} , it is always larger by the factor $\{2eU/kT\}^{1/2}$
- Since kT at room temperature $\approx 1/40$ eV, while applied voltages may be up to **1000 V**, d_{SCR} may exceed L_{Dn} by several orders of magnitude. This is shown in the illustration below (the numbers are basically correct, but not in detail).
- The breakdown limit indicates that the **SCR**, being an dielectric insulator, will eventually experience [electrical breakdown](#) if the field strength exceeds an upper limit.

